




Female Cross



Female Cross

P-NPT Size (in.)	Basic Ordering Number	L	F	E Minimum Opening	B
1/16	CR-NS1	12.7	11.1	4.8	9.9
1/8	CR-NS2	16.8	14.3	8.6	10.4
1/4	CR-NS4	22.4	19.1	11.4	15.0
3/8	CR-NS6	25.7	22.2	15.0	15.0
1/2	CR-NS8	31.2	27.0	18.5	19.8
3/4	CR-NS12	34.5	33.5	23.9	20.6
1	CR-NS16	41.4	41.3	29.7	25.4

Fluid Fit Engineers

Unit 11, Pereira Compound, Near Vaishali Nager, S. V. Road

Mumbai-400 102, Maharashtra (India)